

# Control Commands

Model No. PT-DZ21K2  
PT-DZ20K2  
PT-DZ16K2  
PT-DW17K2  
  
PT-DZ21K  
PT-DZ20K  
PT-DZ16K  
PT-DW17K



- Please refer to the Service Manual or Operating Instructions for the serial command format, limitations, connection and other details.
- シリアルコマンドのフォーマット、制限事項、接続方法およびその他詳細につきましては、各モデルのテクニカルガイドまたは取扱説明書をご覧ください。

















CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		DZ21K2 SERIES				DZ21K SERIES			
				COMMANDS	COMMANDS	CALL BACK	DZ21K2 SDZ21K2C	DS20K2 SDZ20K2C	DZ16K2 SDZ18K2C	DW17K2 SDW17K2C	DZ21K SDZ21KC	DS20K SDZ20KC	DZ16K SDZ18KC	DW17K SDW17KC
NETWORK	DIGITAL LINK STATUS-HDCP STATUS	NO SIGNAL OFF ON			QVX: DKSI 2	DKSI 2=+00000 DKSI 2=+00001 DKSI 2=+00002	✓ ✓ ✓	✓ ✓ ✓	✓ ✓ ✓	✓ ✓ ✓				
	DIGITAL LINK STATUS-SIGNAL QUALITY (MIN)	-255 0			QVX: DKSI 3	DKSI 3=-00255 DKSI 3=+00000	✓ ✓	✓ ✓	✓ ✓	✓ ✓				
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	-255 0			QVX: DKSI 4	DKSI 4=-00255 DKSI 4=+00000	✓ ✓	✓ ✓	✓ ✓	✓ ✓				
	DIGITAL LINK INPUT CH LIST	HDI:HDMI1,HD2:HDMI2...			QVX: DL1S1	DL1S1=HDI: HDMI 1, ****; ***	✓	✓	✓	✓				
	PROJECTOR NAME SETTING	PROJECTOR1		VXX: NCGS8=PROJECTOR1	QVX: NCGS8	NCGS8=PROJECTOR1	✓	✓	✓	✓	✓	✓	✓	✓
	Art-Net SETUP	OFF ON ON(2.*.**) ON(10.*.**) ON(MANUAL)		VXX: DANI 1=+00000	QVX: DANI 1	DANI 1=+00000	✓	✓	✓	✓	✓	✓	✓	✓
				VXX: DANI 1=+00001		DANI 1=+00001	✓	✓	✓	✓	✓	✓	✓	✓
				VXX: DANI 1=+00002		DANI 1=+00002	✓	✓	✓	✓	✓	✓	✓	✓
				VXX: DANI 1=+00003		DANI 1=+00003	✓	✓	✓	✓	✓	✓	✓	✓
	Art-Net SETUP-PORT ADDRESS	OFF 32767		VXX: DANI 2=+00000	QVX: DANI 2	DANI 2=+00000	✓	✓	✓	✓	✓	✓	✓	✓
				VXX: DANI 2=+32767		DANI 2=+32767	✓	✓	✓	✓	✓	✓	✓	✓
	Art-Net SETUP-START ADDRESS	1 501		VXX: DANI 3=+00001	QVX: DANI 3	DANI 3=+00001	✓	✓	✓	✓	✓	✓	✓	✓
				VXX: DANI 3=+00501		DANI 3=+00501	✓	✓	✓	✓	✓	✓	✓	✓
	Art-Net SETUP-NET	0 127		VXX: DANI 4=+00000	QVX: DANI 4	DANI 4=+00000	✓	✓	✓	✓				
				VXX: DANI 4=+00127		DANI 4=+00127	✓	✓	✓	✓				
	Art-Net SETUP-SUB NET	0 15		VXX: DANI 5=+00000	QVX: DANI 5	DANI 5=+00000	✓	✓	✓	✓				
				VXX: DANI 5=+00015		DANI 5=+00015	✓	✓	✓	✓				
	Art-Net SETUP-UNIVERS	0 15		VXX: DANI 6=+00000	QVX: DANI 6	DANI 6=+00000	✓	✓	✓	✓				
				VXX: DANI 6=+00015		DANI 6=+00015	✓	✓	✓	✓				

Note: The commands or parameters with "\*" shows available commands or parameters for the projector which has been activated by the Upgrade Kit.